

BF-20192 HAMPTON BAY COLLECTION SINGE TILT-OUT HAMPERS

INV#26013

ASSEMBLY INSTRUCTIONS

Made In China



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts, which may have came loose inside the carton during shipment. Count all parts and material hardware, then compare with parts list to be sure all parts are present. If any parts are missing or damaged, phone, fax, or mail to our Customer Service Department for efficient and speedy service. Please indicate the model number and code letter of part(s) needed.

IMPORTANT NOTE: Follow instructions listed below in proper sequence as numbered to assure fast, easy and correct assembly.

PARTS LIST	
B	B1
	RIGHT SIDE PANEL-1PC
D	E
BOTTOM PANEL-1PC	BACK PANEL-1PC
G	H
(BUCKET) SIDE PANELS-2PCS	(BUCKET) STICK PANEL-1PC
I	J
BASE PANEL-1PC	BAG-1PC
Ī	BOTTOM PANEL-1PC BUCKET) SIDE PANELS-2PCS [

IV		M
K	L	M
$N = \frac{\text{CAM-LOCKS-8PCS}}{11 \text{mm} \times 1 - 1/4}$	CAM-BOLTS-8PCS	$\begin{array}{c c} & \text{FEET-4PCS} \\ \hline P & 8 \text{mm} \times 1/2 \text{"} \end{array}$
		T Omm 172
Dannan .		O
GONEWG ADGG	WNOD ADG	
SCREWS-4PCS Q	KNOB-1PC	$\frac{\text{SCREWS-1PC}}{\text{S}}$ 7mm × 19/32"
۵		A
DOWELS-4PCS	HINGES-2PCS	SCREWS-12PCS
T	U	V 6mm × 3/4"
		De la companya della companya della companya de la companya della
		DIIIII.
ALLEN WRENCH-1PC	CAM-TOOL-1PC	SCREWS-23PCS


NOTE: THE SURFACE WITH THE STICKER IS THE BACK SIDE.


NOTE: • UPON OPENING, THOROUGHLY CLEAN ALL WOODS SURFACES TO REMOVE DUST

AND DIRT THAT MAY HAVE SETTLED ONTO FINISH DURING SHIPMENT. IN ORDER

TO PREVENT DAMAGE DURING ASSEMBLY, PLEASE ASSEMBLE THIS ITEM WITH AT

LEAST TWO PEOPLE.






NOTE: TURN THE CAM-BOLT SCREWS UNTIL THEY


ARE TIGHT, THE SHOULDER SHOULD BE

AGAINST THE SURFACE OF THE PART.


HOW TO USE THE CAM-TOOL



NOTE: • THE ARROWS ON THE HIDDEN CAM-LOCKS SHOULD POINT TO THE CAM-BOLTS




- $\textcircled{1} \bullet \mathsf{ATTACH} \ \mathsf{STICK} \ \mathsf{PANEL}(\mathsf{H}) \ \mathsf{USING} \ \mathsf{6} \ \mathsf{SCREWS}(\mathsf{V}) \ \mathsf{AND} \ \mathsf{ATTACH} \ \mathsf{KNOB}(\mathsf{0}) \ \mathsf{UISNG} \ \mathsf{SCREWS}(\mathsf{P}).$
- ② ATTACH SIDE PANEL(G) TO STICK PANEL(H) USING SCREWS(V).
- ③ INSERT BASE PANEL(I) INTO THE SLOT IN THE PANEL(G/H).
- (4) ATTACH BACK PANEL(H1) TO SIDE PANEL(G) USING SCREWS(V).




2).ASSEMBLE THE FEET(M).

● ATTACH 4 FEET(M) TO BOTTOM PANEL(D) USING SCREWS(N).




3).ASSEMBLE SIDE PANEL(B/B1) AND BOTTOM PANEL(D).

- INSERT 4 DOWELS(Q) INTO THE HOLES IN THE BAFFLE PANEL(C) AND SIDE PANEL(B/B1).
- ROTATE THE 4 CAM-BOLTS(L) INTO THE HOLES IN THE BOTTOM PANEL(D).
- PLACE CAM-BOLTS(L) INTO THE HOLES IN THE PANEL(B/B1) AND ATTACH USING 4 CAM-LOCKS(K).




4).ASSEMBLE TOP PANEL(A).

- ROTATE THE 4 CAM-BOLTS(L) INTO THE HOLES IN THE TOP PANEL(A).
- PLACE CAM-BOLTS(L) INTO THE HOLES IN THE PANEL(B/B1) AND ATTACH USING 4 CAM-LOCKS(K).
- ATTACH BAFFLE PANEL(C) USING SCREWS(V) IN THE PREDRILLED HOLES OF TOP PANEL(A)



5) <u>ASSEMBLE DIRTY CLOTHING BUCKET.</u>

- PUT THE BAG(J) INTO THE BUCKET.
- ullet INSERT THE HINGES(R) INTO THE HOLES IN THE (BUCKET)FRONT PANEL(F).
- PLACE THE HINGES(R) BETWEEN INTO THE HOLES IN THE SIDE PANEL(B/B1).



6). ASSEMBLE THE BACK PANEL(E).

• ATTACH THE BACK PANEL(E) TO TOP/BOTTOM/SIDE PANEL USING SCREWS(S).